

---

## Edit the channel list

What is a bouquet? A bouquet can be thought of something like a folder. Every channel equals a page in this folder and the pages are sorted into categories.

This way you can create a bouquet called “Kids”, for example, under which you “file” all children’s stations. Another example would be to create a bouquet called “Sports“ where you put all sports channels. This way you can create several topic related bouquets.

***Note!***

*You can only delete channels in the “favorites view”!*

You cannot delete the channels in the “All” view. The use of the “All” view is to keep an internal list of all available stations. If you start a new channel search the result would be saved to the “All” view for example. Your favorites bouquet will stay untouched. This way you can easily add newly found channels from the “All” list to your favorites bouquet.

## Adding a bouquet

---



To be able to add a bouquet you have to set the "Allow multiple bouquets" option to yes.

Pressing the **Up/Down-Buttons** on your remote control activates the service list.



Press the **blue Options-Button** to switch to the bouquet view.



By pressing the **Menu-Button** the "Channellist menu" will open up.

Navigate to the option "add bouquet".

Use the **Numeric-Keypad** on your remote control to enter the name for the new bouquet. The according letters are printed on button.

The **Mute-Button** and the **Arrow-Left/Arrow-Right-Button** deletes a character.

Press the **OK-Button** to add the new bouquet to your

favorites list. You will be taken back to the "Channellist menu".

## Add a service to favorites

---

If you want to add a service to your **Favorites-view** you can choose from services in the **All-, Satellites-and Provider-views**. You can switch views by pressing the **red, green, yellow and blue Options-Buttons**. At this point we only describe the process from the **All-Bouquet** since it is the

same for the others.



Pressing the **Up/Down-Buttons** on your remote control activates the service list.

Press the **red Options-Button** to change to the All view.

Use the **Navigation-Buttons up/down** to select the desired service and press the **MENU-Button** to open the "Channellist menu".



Navigate to the option "add service to bouquet".

If you are using more than one bouquet this option is named "add service to bouquet" instead and you will get a list of your bouquets afterwards. You can choose to which bouquet you want to add the currently selected service. If you are using only one bouquet which is the factory default, the service will be added to you favorites list.

# Adding multiple services to a bouquet

You can select multiple services from the All-view to be added to the currently selected bouquet.



Pressing the **Up/Down-Buttons** on your remote control activates the service list.

Use the **Bouquet +/- Buttons** to switch to the desired bouquet. As an alternative you can press the **blue Options-Button** and select the desired bouquet.

After that select a service and switch to it by pressing the **OK-Button**.



By pressing the **Menu-Button** the "Channellist menu" will open up.

Navigate to the option "enable bouquet edit". The Allview will open up.



All services that are in the selected bouquet are highlighted red.

Use the **Up/Down-Buttons** to navigate to a desired service and press the **OK-Button** to select. The service will be highlighted red. Using this method you can select additional services that you want to add to the bouquet.

Once you have selected all services that you want to add, press the **Menu-Button**. The "Channellist menu" will open up.



Choose the "End bouquet edit" option. All highlighted services will now be added to the bouquet that you selected in the beginning.


If you are only using one bouquet, which is the default setting, the selected services will be added to you favorites list.

## Remove a service from favorites

---



Pressing the **Up/Down-Buttons** on your remote control activates the service list. Use the **Navigation-Buttons up/down** to select the desired service and press the **MENU-Button** to open the “Channellist menu”.



Navigate to the option “remove service”. The selected service will be deleted from your favorites list.

## Moving a service to favorites



Pressing the **Up/Down-Buttons** on your remote control activates the service list.

Use the **Navigation-Buttons up/down** to select the desired service and press the **MENU-Button** to open the “Channellist menu”.



Navigate to the option “enable move mode” and press the **OK-Button**.



Use the **Navigation-Buttons up/down** to select the service that you want to move and press the **OKButton**. The service will be highlighted red.



Use the **Navigation-Buttons up and down** to move the service to the desired position. Press the **OKButton** to release the service and thus placing it at it's new position.

You can move services as long as the move mode is activated. To disable the move mode press the **MENUButton** to get into the “Channellist menu” and chose the option “disable move mode” by pressing the **OKButton**.